




Controller Model: **Animatics SmartMotor™ Series**
 Maple OIT Model: **OIT3100 and OIT4100 Series**
 Communication Type: **RS-232 with DE9 connector at Controller**

Use the wiring diagram and illustration to assemble a communication cable for use with an Animatics SmartMotor Series Controller. This cable requires the Animatics SmartMotor cable assembly (CBLSM1-10).



NOTES:

- 1 Install heatshrink on shield (bare wire) to avoid shorting.
- 2 Connect shield wire to the metal housing of the RJ-45 connector.

