

CABLE ASSEMBLY INSTRUCTION

Maple Model(s)

HMI5043

PLC or Controller

Aerotech Soloist, Ensemble
Controllers

Communication Type


RS-232 with Leads at
Controller



Summary

Use the wiring diagram and illustration to assemble a communication cable for use with an Aerotech Soloist CL/CP/ML/MP, or Ensemble CL/CP/MC/MP controller.

Drawing and Schematic



NOTES:

- 1 Shield wire must be terminated to connector metal shell.

