

CABLE ASSEMBLY INSTRUCTION

Maple Model(s)

HMI5000 Series (COM1)
HMI600 Series

PLC or Controller

Aromat FP2

Communication Type


RS-232 with DE9 at PLC



Summary

Use the wiring diagram and illustration to assemble a communication cable for use with an Aromat FP2 PLC.

Drawing and Schematic



MAPLE HMI END

PLC END

NOTES:

- 1 Shield wire must be terminated to connector shell.

