

CABLE ASSEMBLY INSTRUCTION

Maple Model(s)

HMI5000 Series
HMI500 Series
HMI600 Series

PLC or Controller

Ethernet Crossover Cable

Communication Type


Ethernet Crossover with RJ-45 on Both Ends of Cable



Summary

Use the wiring diagram and illustration to assemble a communication cable for use with a device using an Ethernet port which requires a crossover Ethernet cable.

Drawing and Schematic



MAPLE HMI END

PLC END

